


# ECV-BNC TRANSMITTER OPERATION GUIDE



## **INSTRUCTIONS:**

- 1) Connect the camera to the transmitter, as shown above.
- 2) Then, connect the transmitter to the receiver with twisted pair wires, connecting positive to positive, and negative to negative.
- 3) Then, connect the receiver to the monitor.