

Quick Start Guide to PDP-1-4K Digital Signage Player

Dear Customer,

Congratulations on your purchase of PDP-1-4K Digital Signage Player from Pragmatic Communications Systems, Inc.

The unit is shipped pre-configured to get you up and running immediately.

1) Please properly unpack the unit and verify all its contents. You will need two AAA batteries for the remote control. A USB mouse is optional but will make configuration easier.



2) Connect a HDMI monitor, audio power amplifier + PHA speaker and USB mouse to the unit. If you are connecting to a 10/100 Ethernet, please connect the cat5e/cat6 cable to the LAN port. If you will be connecting to a wireless network, please make sure the antenna is connected properly to the unit. Please note, remote control and USB mouse are not required for normal operation of the unit. These can be used only to configure the unit. The system is configured for auto-boot and auto-start after power reset/power failure automatically.


3) Connect the 12VDC Power adaptor to the unit and set the power switch to **ON** position. The unit will start playing the content pre-loaded in the internal memory.



CONNECT TO A NETWORK:

Point the remote to the IR detector on the front of the unit and press **F1**. The unit will exit the playback loop and show the following on the monitor screen.

If you are using the USB mouse instead, move the cursor to the top left corner of the screen and **left-click the mouse button 8 times**. The following '**Main menu**' should appear on the monitor screen. The 'Network' icon is high-lighted on the screen.




Press '**OK**' on the remote control or left-click with the mouse on the '**Network**' icon. The following network configuration screen will appear on the monitor.

{Network Configuration Screen image goes here}

If using hard-wired connection to the Ethernet via Cat5e/Cat6 cables follow the instructions below for **Ethernet connection**. If using Wi-Fi connection, skip to the **Wi-Fi connection** section. For configuration of the optional 3G/4G Mobile connection or PPPoE connection, please refer to the **PDP-1-4K User's manual**.

Ethernet connection:

Press the '**UP arrow**' button on the remote until the '**Ethernet**' icon is high-lighted and then press '**OK**', or move the cursor and left-click the mouse button on the '**Ethernet**' icon. The Ethernet configuration screen will pop-up as shown below.




If your network supports DHCP, please select '**Obtain IP from a DHCP server**' as shown in the screen above. If you wish to configure for static IP address, please select '**Use the static settings below**' and enter the IP address, Subnet Mask, Network Gateway and DNS Server information. Obtain this information from your network administrator. A pop-up keyboard will appear on the screen to facilitate entry of the data.

After the appropriate selection, press '**OK**'. The network configuration screen will appear. Press '**OK**' again and return to the main menu screen. The settings will take effect only after the player reboots. Select the '**Reboot**' icon and press '**OK**' on the remote control or left-click mouse button. The unit will reboot and return to '**Standby**' state. Press the 'Power' button on the remote control or toggle the power on/off switch to restart the unit.

Wi-Fi connection:

Press the '**UP arrow**' button on the remote until the '**WiFi**' icon is high-lighted and press '**OK**', or move the cursor and left-click the mouse button on the '**WiFi**' icon. The WiFi configuration screen will pop-up as shown below.




If you know your WiFi network SSID and password, please enter the information in the appropriate boxes and click '**OK**'. The network configuration screen will appear. Press '**OK**' again and return to the main menu screen. The settings will take effect only after the player reboots. Select the '**Reboot**' icon and press '**OK**' on the remote control or left-click mouse button. The unit will reboot and return to '**Standby**' state. Press the 'Power' button on the remote control or toggle the power on/off switch to restart the unit.

If you do not know the SSID, you can click on the '**Search**' button to scan for available WiFi networks. The unit will scan and display available WiFi networks. Select the correct network, enter the password information and click '**OK**'. The network configuration screen will appear. Press '**OK**' again and return to the main menu screen. The settings will take effect only after the player reboots. Select the '**Reboot**' icon and press '**OK**' on the remote control or left-click mouse button. The unit will reboot and return to '**Standby**' state. Press the 'Power' button on the remote control or toggle the power on/off switch to restart the unit.


CONFIGURE THE PDP-1-4K PLAYER:

Point the remote to the IR detector on the front of the unit and press **F1**. The unit will exit the playback loop and show the following on the monitor screen.


If you are using the USB mouse instead, move the cursor to the top left corner of the screen and **left-click the mouse button 8 times**. The following '**Main menu**' should appear on the monitor screen. The '**Network**' icon is high-lighted on the screen.



Press the right arrow key on the remote control and press '**OK**' or place the cursor on the '**Player**' icon and left-click with the mouse button. The following player configuration screen will appear on the monitor.



Player ID, Corp ID and Player Name can be set by clicking on the 'Setup' icon. Following screen will appear where the information can be updated or changed.



After making all the desired changes to the player's settings, return to the main menu screen. The settings will take effect only after the player reboots. Select the '**Reboot**' icon and press '**OK**' on the remote control or left-click mouse button. The unit will reboot and return to '**Standby**' state. Press the 'Power' button on the remote control or toggle the power on/off switch to restart the unit.

Please refer to the PDP-1-4K User's Manual for further details on the operation of the unit and advanced settings.

Or contact us via phone or email. (sales@Pragmatic1.com) for technical support.

Once again, thanks for purchasing PDP-1-4K from Pragmatic Communications Systems, Inc.